



TempMinder® MRC257JW Instructions

Congratulations on your purchase of the TempMinder MRC257JW. We hope you find these instructions user friendly and easy to follow.

- Remove protective cover from display front.
- Remove the clear plastic tab from the battery compartment. The display will now be activated.

Study the buttons across the bottom of the display:

Mode / Set / ADJ (adjust) / Snooze / Reset

Early Hints;

- Read each section prior to programming
- **Set** and **Adjust** are your main buttons
- When you push a button, make sure you push to hear the beep.
- Avoid pressing the Reset button as it will clear all information.
- You have from 5 to 10 seconds to enter the next piece of information. If you need more time, the unit will go back to the default setting. Simply restart the section you were working on (A, B, C, etc).
- Under no circumstances should you let it “get to you”! It’s only a computer-like device and you cannot screw it up unless you throw it out the window (in which case it will not be under warranty!)
- The most difficult may be the setting of the Hi/Lo temperature/humidity alarms. If you have no need of these features, just skip sections F, G & H. Otherwise, just follow the directions and have fun.
- When humidity drops below 20%, display shows “LL”. If higher than 90%, display shows “HI”. Humidity is accurate to +/- 5%.
- Battery type 1.5V G10-A. When replacing, plus (+) side is up.

READY-SET-GO!!!!

A) TO SET CLOCK:

- Choose 12 hr or 24 hr (Military) mode.
- Press & hold “SET” button for 3 seconds. “12HR” will flash. Press “ADJ” button to change to 24 HR – press “SET” to confirm either 12 or 24 format when either one is flashing.
- Next, “minutes” will flash; Press “ADJ” until you have the correct “minute” displayed. Press set to confirm,
- Next, “hours” will flash. Press “ADJ” until you have the correct “hour” displayed. Be sure you are in either AM (upper icon) or PM (lower icon) mode. Press “SET” again to confirm the correct hour setting. Congratulations, you’ve just programmed the clock!

B) TO SET THE CALENDAR:

- Press the “MODE” button 2 times.
- Press & hold the “SET” button for 3 seconds.
- The year will flash. Press the “ADJ” button until the correct year comes up.
- Press “SET” to confirm.

- Next the month will flash. Press the “ADJ” button until you see the current month.
- Press “SET” to confirm.
- Now the day date will flash. Press the “ADJ” button to get to the correct day. Press “SET” to confirm.

C) TO SELECT °C or °F:

- Simply press the “SET” button one time. Don’t you wish the rest was this easy!

D) TO SELECT IN OR OUT TEMPERATURES:

- Press the “MODE” button five (5) times.
- The “in” icon will flash. Press “ADJ” one time.
- The “out” icon will flash. Press the “MODE” button (NOT THE SET BUTTON), to confirm.
- This procedure will be required anytime you want to switch between indoor and outdoor temperatures.

E) POSITION YOUR NEW TEMP MINDER® NEAR THE WINDOW (not in the sun). Extend the wired probe outside. Take care not to damage the wire when closing the window (it should be thin and flexible enough to fit through most sills).

OK, your TempMinder® will now display the current time, day, in or out temperature, inside humidity, moon phase and weather symbol (based on humidity). Well done!

You can stop there if that’s enough information.

The rest of the features not yet covered include;

- Alarm setting for time
- High/Low Temperature Alarms
- High Low Humidity Alarms
- Min/Max Temperature History
- Min/Max Humidity History

If you really, really need any of these additional features, read on. Otherwise, you’re all set – **enjoy your new TempMinder®.**

F) TIME ALARM SET: There are four settings of alarm indication to choose from:

- 0) alarm off/hour alarm off (no bell symbol displayed)
- 1) alarm on/hour alarm off (bell symbol displayed)
- 2) alarm off/hour alarm on (no bell symbol)
- 3) alarm on/ hour alarm on (bell symbol displayed)

- Press mode button once, look for “AL” display in the “DAY” box. Press set button for 3 seconds, hour & minute will flash. At this point the unit will be in setting 0.
- When hour & minute begin to flash choose 1 thru 3 by depressing the ADJ button. Yes, you will need to count how many times you depress the “ADJ” button.
- For the basic time alarm (#1 above), you will only need to depress the “ADJ” button once.
- To select alarm time, press set button until minute flashes, adjust by pushing ADJ button, press “SET” to confirm. Hour will now flash. Press “ADJ” for the hour you need. Press “SET” to confirm.
- Note: The alarm will stop after 1 minute if no button is pressed.
- To silence alarm, press any button except snooze.
- Press snooze button if you need an extra 5 minutes.

G) Low/High Temperature and Humidity Alarm Mode:

Press “MODE” - 3 times for low temperature set mode –low icons
- 4 times for high temperature set mode – high icons
-3-

- You can now use the following for either low or high temperature setting.
- Press & hold set button until icon is flashing, use ADJ button to on/off alarm (ON – icon appears to the left of the temperature, OFF - no icon displayed).
- Note - you can only set temperature values for low or high alarms if in “alarm on” condition and left icon is flashing at the same time as the temp mode icon (low or high).
- Under low or high temperature alarm on condition, press set button until temperature item setting is blinking, press ADJ to set the item value
- Press set to enter humidity alarm setting mode, with icon flashing above the humidity use ADJ button to on/off the alarm. Look for the icon to the left of the humidity reading indicating alarm on. In alarm on condition, press set button, humidity item is blinking, press ADJ button to set item value.

H) Min/Max Temperature & Humidity History:

- Min/Max history will be displayed for either “in” or “out” depending on current setting.
- Press “SET” once.
- Press ADJ button once to show maximum temperature and humidity.
- Press ADJ button again to show minimum temperature and humidity.
- Press ADJ button for 5 seconds to clear the Min/Max histories.

Phewfff!!! All of us at Minder Research want to Thank You for purchasing our product. Please check out our website as we have many products you Must Have!!!!!!

This product is guaranteed against manufacturing defects (not including batteries) for a period of one year. Should it fail, return it to the address below (with a copy of your receipt).

Minder Research Inc. P.O. Box 47 Port Salerno, FL 34992
3000 SE Waaler Street, Stuart, FL 34997

www.MinderResearch.com
info@MinderResearch.com