



## TempMinder® MRI-125AG w/Photo Frame

Thank you for purchasing the new TempMinder® MRI-125AG w/Photo Frame. We have attempted to make these directions as simple to follow as possible (no engineers were allowed input). If you have any problems or questions, feel free to contact us (info below).

### **Overview & setup instructions:**

To insert a personal 4" x 6" photo, simply slide the protective Plexiglas up, position your photo behind the Plexiglas and slide both back into position.

In order to make it easier to program the various functions, you will have a full 60 seconds to complete each step. It's also a good idea to familiarize yourself with the buttons on the back. It helps if you do not need to turn the unit over for each input.

### **So, let's get started!**

Insert 2 AAA batteries in the rear of the unit. We recommend you use alkaline type for better performance and longer life. Be sure to follow the +/- directions (inside the battery compartment).

### **To Set Time & Date:**

- Press "MODE" – 12hr will flash. Press "UP" or "DOWN" to select the 12hr or 24hr time display.
- Press "SET" to enter the time setting mode. The hour will flash. Press "UP" or "DOWN" to reach the desired hour.
- Press "SET" to confirm – the minutes will flash – press "UP" or "DOWN" to select the minutes.
- Press "SET" to confirm. The Year, Month and Date will follow. Program each using the same procedures as before.
- When you are back to the 12/24hr display, press the "MODE" button 4 times or wait 60 seconds.

If you have done all this on the first pass, CONGRATULATIONS – you're an expert programmer! At this point your TempMinder® is ready to go. You should see the current temperature (in °C), the time, month, date and day. **To switch from C to F, simply press the "SET" button once.**

Be sure to keep these instructions. You will need them when you replace the batteries and when you want to program the **Alarm/Snooze, Birthday Reminder or Countdown Timer functions.**

### **Alarm/Snooze Function:**

- Press "MODE" twice – press "SET" – hour will flash – press "UP/DOWN" to select desired hour
- Press "SET" to confirm – repeat for desired minutes – Press "SET" to confirm.
- Upper left corner will flash "1". Select a number between "1" and "9". These are all different musical "tunes" or "beep" types (have fun!).
- Press "MODE" three times to exit and confirm the alarm setting.
- Press "UP" to activate the Snooze "Zzz" will appear above the minutes.

When the alarm is active, it will play the selected tune or beep for one minute. To stop, press any button. If the snooze is set, the alarm will reactivate every four minutes (4 times only).

To disengage the alarm – press "ALARM" once then press "SET" 5 times. -:- will appear. Press "MODE" 3 times to return to the normal viewing mode (without the "BELL" icon).

To reengage the alarm, press "ALARM" once – Press "SET" once (alarm time will be displayed) – press "MODE" 3 times to return to the standard viewing mode (alarm "BELL" icon will be back).

**Birthday (Special Occasion Reminder):**

- Press "MODE" three times
- Press "SET" to program Hour, Minute, Year, Month and Day using the "UP/DOWN" buttons.
- When complete, press "MODE" key twice to confirm and exit

When that special day and time arrives, the TempMinder will play "Happy Birthday" for 5 minutes. Sorry, there is not anniversary or valentine tune.

**Countdown Timer:**

- Press "MODE" four times
- Press "SET" then "UP/DOWN" for the hour
- Press "SET" to confirm then "UP/DOWN" to select the desired minutes.

The next time you press "SET", the countdown will begin. When the time expires, you will hear "Charge of the Light Brigade" (very cool!!). It will last for one minute unless you press any button to cancel.

- Time range 0-23 hours – 0-59 minutes (0.01 – 23.59)

**TempMinder MRI-125AG Specifications:**

- Photo Size 4" x 6"
- Calendar 2000 through 2099
- Temperature Range 0°C - 70°C (32°F - 122°F)
- Accuracy +/- 1°C (1.8°F)
- Countdown timer 0.01-23.59
- Power 3.0v 2-AAA (not included)

Note: Pressing "DOWN" while in the regular viewing mode will activate all "tunes" to play continuously (that's non-stop). Press any button to cancel.

WARRANTY; This product is guaranteed against manufacturing defects for a period of one year. Should it fail, return it to the address below (with a copy of your receipt). If you drop it, or your dog chews it up, please just buy a new one!!!! ENJOY

Minder Research Inc

P.O. Box 47, Port Salerno, FL 34992

[www.MinderResearch.com](http://www.MinderResearch.com)

[info@MinderResearch.com](mailto:info@MinderResearch.com)

©2010 The Minder Research Incorporated