



3000 S.E. Waaler Street
Stuart, Florida 34997 USA
772.463.6522 office
772.463.8361 fax
www.MinderResearch.com

Supplement to TempMinder®MRI-177AN instructions:

“How to change time zones”

On the rear of the receiver, press and release the “satellite dish” button. With the icon displayed on the front, press and release the “zone” button until your desired time zone appears (PA-Pacific, MO-Mountain, CE-Central or EA-Eastern). Sorry, there is no NF for Newfoundland as the signal from Colorado does not reach that far. Once you see the correct zone, you may press the “clock” button on the top of the unit or wait 15 to 20 seconds for it to register. When the MRI-177AN receives the next transmission from Colorado, it will automatically set the correct time for your zone.

CF-06/26/11